

Pieces needed for realizing a window/door following L and H dimensions.

PCS	DESCRIPTION	CODE	H	600 1800	1801 2800	600 1400	1401 2800	600 1400	1401 2800	1401 2800	Secondary leaf
			L	350 509	510 1200	1201 1400	1401 1700				
5	(pat.) Basic kit with standard arm, vertical fulcrum	1246.1					1				
5	(pat.) Basic kit with standard arm, horizontal fulcrum	1246.13					1				
5	(pat.) Basic kit with short arm, vertical fulcrum	1246.3	1								
5	(pat.) Basic kit with short arm, horizontal fulcrum	1246.14		1							
5	(pat.) Adjustable clamp in hinge kit	1246.705					1				
20	Corner reinforcement (*)	1246.736					1				
5	Supplementary arm	1246.800							1		
1	Jig for accessories positioning	1246.950					1				
1	Jig for accessories positioning	1246.952	1				1				
5	Kit for 6 locking points	1246.801				1				1	
40	Locking piece	1243.701		1							1
40	Adjustable keeper	1243.725		2							2
10	Lower corner drive	1243.801		1							
5	(pat.) Clamp in hinge kit for secondary casement	1246.803									1
20	(pat.) Clamp bolt	1541.7									2
20	Clamp-bolt	1243.804									
100	Keeper	1405.1									2
40	Hinge-side supplementary closing point (H>1400 mm)	1246.839									1

(*) = To be used for doors and windows which weight is from 80 to 120 Kg

